

La-Z-Boy Rocker Recliner

For more information visit
www.la-z-boy.co.uk

La-Z-boy[®]

Version 0126

Safety and usage

The rocking function is operated by turning the dial situated to the left of the chair main operation panel. Position zero is off, and settings 1 to 5 gradually increase the rocking speed of the chair.

It is important to note that heavier people will experience a longer rocking motion (length of travel) than lighter people. This is perfectly normal and a feature of the chair.



Further product documentation
can be found at
la-z-boy.co.uk/productguides
or scan the QR code.



La-Z-boy

www.la-z-boy.co.uk